


O-2-O



Hours, minutes and seconds



Date



Day of the week

To set the clock, proceed in the following order:

1- Setting of:

Day

2- Setting of:

Minutes




Hours

3- Setting of:

Date




1



Setting of:

Day



1- Pull the crown out two positions




2- Turn the crown clockwise to set the Day (do not turn counterclockwise)

3- The day of the week hand advances every 24h (two turns of the hour hand)

NOTE: to be sure that the Day remains set correctly, do not perform this operation between 9:00 PM and 1:00 AM


2



Setting of:

Minutes

Hours



1- Pull the crown out two positions




2- Turn the crown clockwise to advance the Minute and Hour hand and set Hour and Minutes

3- Push the crown back in by two positions

NOTE: Make sure you set the AM or PM time correctly




3



Setting of:

Date



1- Pull the crown out one position



2- Turn the crown counterclockwise to set the Date

3- Push the crown back in

NOTE: to be sure that the Date remains set correctly, do not perform this operation between 9:00 PM and 1:00 AM

Note: Use batteries SR621W, 364

